

**DIMENSIONS
FLOOR FINISH STRIPPER**

TECHNICAL DATA SHEET



GENERAL INFORMATION

DIMENSIONS FLOOR FINISH STRIPPER is an advanced formula that features heavy-duty performance, handling the toughest floor finish stripping jobs. DIMENSIONS is low odor and leaves no alkaline residue making stripping faster, easier and without offensive fumes. Neutralizing rinses are not necessary if solution is properly picked up.

- Low Odor Formula
- Liquifies the Most Difficult to Remove Finishes
- May be Used with Cold Water
- Use as Mop On Application or in Machine Operation
- Leaves No Alkaline Residue
- No Rinse Formula Saves Time and Labor
- Recommended for Use in Hospitals and Nursing Homes
- Heavy Duty Liquifying Performance

RECOMMENDED DILUTIONS

| | | | | | |
|---|-------------|------|--------------------------|-------------|------|
| Dilute with cold water. NOTE: Do not use hot water. | | | | | |
| Mop Stripping | | | Machine Stripping | | |
| For light build-ups: | 13oz./gal. | 1:10 | For light build-ups: | 11 oz./gal. | 1:12 |
| For normal build-ups: | 21 oz./gal. | 1:6 | For normal build-ups: | 14 oz./gal. | 1:9 |
| For heavy build-ups: | 42 oz./gal. | 1:3 | For heavy build-ups: | 21 oz./gal. | 1:6 |

Machine Stripping

1. Dust mop to remove loose soil and grit from floor surface.
2. Dilute as shown above.
3. Spread stripper generously over a manageable area and allow stripper to stand for at least 5 minutes. Important: Do not allow stripping solution to dry on floor at any time. Add additional solution as needed.
4. Machine scrub with floor machine or auto scrubber with stripping pad or appropriate grit brush until all floor finish is completely liquefied.
5. Pick up solution with mop or wet pickup vacuum.

Mop Application:

1. Follow directions 1 through 3 above.
2. Agitate stripping solution with mop until old finish is completely liquefied.
3. Pick up solution with mop or wet pickup vacuum.

Note: A single rinse is recommended to remove any pieces of mop head and/or floor pad.

CAUTIONS: Contains Amine. Use only with adequate ventilation. Avoid contact with eyes and skin. Wash hands after using.

FIRST AID: In case of eye contact, flush thoroughly with large amounts of water for 15 minutes and get medical attention. For skin contact, wash thoroughly with soap and water. In case of respiratory difficulty, provide fresh air and call a physician. If swallowed, get medical attention immediately.

WARNING: This product contains a chemical known to the State of California to cause birth defects or other reproductive harm.

SPECIFICATIONS:

- APPEARANCE:** Clear Straw
- FRAGRANCE:** Mild Sweet
- pH:** 13.5 ± 0.5
- DILUTION:** As recommended above
- % ACTIVE INGREDIENTS:** 25
- VISCOSITY:** 1
- FLASH POINT:** >100C
- SOLUBILITY:** Completely in water
- FREEZE/THAW STABILITY:** Stable (minimum 3 cycles)
- SHELF LIFE:** Minimum 1 year from manufacturer date of sale

Cello Professional Products

1354 Old Post Road
 Havre de Grace, MD 21078
 Toll Free: 800-638-4850
 www.cello-online.com