



## PULVERIZE FLOOR STRIPPER

Z51

# TECHNICAL DATA SHEET

### GENERAL INFORMATION

PULVERIZE is the result of extensive research into the chemistry of the removal of today's new floor finishes.

PULVERIZE is a powerful stripper, unsurpassed in effectiveness against problem build-ups generated by super high speed burnishing and constant spray buffing. PULVERIZE is recommended for use on all types of resilient and hard surface flooring except wood.

### RECOMMENDED DILUTIONS

Dilute with cool water. NOTE: Do not use hot water.

For light build-ups	13 oz./gal.	1:10
For medium build-ups	21 oz./gal.	1:6
For heavy build-ups	42oz./gal.	1:3

Important: Older asphalt tile floors may bleach or discolor. Use a dilution of 1 part PULVERIZE to 6 parts water and test a small area. Do not use on linoleum, rubber, or cork. Do not allow contact with aluminum surfaces.

### DIRECTIONS FOR AUTOMATIC SCRUBBERS:

1. Dilute PULVERIZE according to directions, in the detergent solution tank. Release stripper generously over a manageable area with squeegee in up position.
2. Allow stripper to remain in contact with floor for at least 5 minutes. Scrub area until old finish is completely liquified. IMPORTANT: Do not allow stripper to dry on floor.
3. Pick up simultaneously during final scrub. Areas along baseboards and in corners may need to be done by hand using Cello ON & OFF and a doodle bug or stripping pad center.
4. Rinse area with cool, clean water using clean string mops, until there is no evidence of residue left on the floor. Allow to dry thoroughly.
5. Floor is now ready for recoating with any Cello quality floor finish.

### DIRECTIONS FOR MACHINE OR MOP STRIPPING

1. Spread properly diluted PULVERIZE over a manageable area of the floor with a mop. Allow stripper to stand for at least 5 minutes. IMPORTANT: Do not allow stripper to dry on floor at any time.  
FOR MOP STRIPPING: Agitate stripping solution with mop until old finish is completely liquified.  
FOR MACHINE STRIPPING: Scrub floor with machine equipped with stripping pad or grip brush until old finish is completely liquified.
2. Pick up stripping solution with mop, wet pick-up vacuum, or auto scrubber.
3. Before any remaining stripper can dry, rinse floor thoroughly with cool, clean water and clean mop until all residue is removed. Allow floor to completely dry.
4. Floor is now ready for application of any Cello quality floor finish.

**DANGER:** Corrosive to eyes and skin. Contains caustic materials and 2-butoxyethanol. Use with adequate ventilation harmful if swallowed. Avoid contact with skin and eyes.

**FIRST AID:** In the event of eye contact, flush eyes with large amounts of clear water for at least 15 minutes. If irritation persists, seek medical attention. In the event of skin contact, immediately wash off with large amounts of water. If irritation persists, seek medical attention. In the event of overexposure due to inhalation, remove victim to fresh air. If symptoms persist seek medical attention. If swallowed, do not induce vomiting. Drink large amounts of fruit juice or water. Do not give anything to an unconscious person. Seek immediate medical attention.

### SPECIFICATIONS:

**APPEARANCE:** Slight yellow liquid

**FRAGRANCE:** Butyl

**pH:** 13.7

**DILUTION:** As recommended above

**FLASH POINT:** None

**FREEZE/THAW STABILITY:** Stable, minimum 3 cycles

**SHELF LIFE:** Minimum 1 year from manufacturer date of sale

**Cello Professional  
Products**

1354 Old Post Road  
Havre de Grace, MD 21078  
Toll Free: 800-638-4850  
www.cello-online.com

Z51 0405