



TECHNICAL DATA SHEET

GENERAL INFORMATION

DEEP STRIP is specifically designed for removing very highly burnished and particularly difficult to remove films from resilient flooring and non-resilient stone and concrete. Its low-foaming formulation may be applied through automatic scrubbing machines equipped with the proper stripping pads or brushes. May also be mopy machine.

RECOMMENDED DILUTIONS

Dilute with cool water. Do not use hot water.					
Machine Stripping:			Mop Stripping:		
Light Build-ups	11 oz./gal.	1:12	Light Build-ups	13 oz./gal.	1:10
Normal Build-ups	13 oz./gal.	1:10	Normal Build-ups	21 oz./gal.	1:6
Heavy Build-ups	16 oz./gal.	1:8	Heavy Build-ups	42 oz./gal.	1:3

Important: Older asphalt tile floors may bleach or discolor. Use a dilution of 1 part DEEP STRIP to 6 parts water and test a small area. Do not use on linoleum, rubber, or cork. Do not allow contact with aluminum surfaces.

DIRECTIONS FOR AUTOMATIC SCRUBBERS:

1. Dilute DEEP STRIP according to diRelease stripper generously over a manup position.
2. Allow stripper to remain in contact with floor for at least 5 minutes. Scrub area until old finish is completely liquified. IMPORTANT: Do not allow stripper to dry on floor.
3. Pick up simultaneously during final scrub. Areas along baseboards and in corners may need to be done by hand using Cello ON & OFF and a doodle bug or stripping pad center.
4. Rinse area with cool, clean water using clean string mops, until there is no evidence of residue left on the floor. Allow to dry thoroughly.
5. Floor is now ready for recoating with any Cello quality floor finish.

DIRECTIONS FOR MACHINE OR MOP STRIPPING

1. Spread properly diluted DEEP STRIP over a manageable area of the floor with a mop. Allow stripper to stand for at least 5 minutes. IMPORTANT: Do not allow stripper to dry on floor at any time.
FOR MOP STRIPPING: Agitate stripping solution with mop until old finish is completely liquified.
FOR MACHINE STRIPPING: Scrub floor with machine equipped with stripping pad or grip brush until old finish is completely liquified.
2. Pick up stripping solution with mop, wet pick-up vacuum, or auto scrubber.
3. Before any remaining stripper can dry, rinse floor thoroughly with cool, clean water and clean mop until all residue is removed. Allow floor to completely dry.
4. Floor is now ready for application of any Cello quality floor finish.

DANGER: Corrosive to eyes and skin. Contains caustic material and 2-butoxyethanol. Use with adequate ventilation. Harmful if swallowed.

FIRST AID: EYES: Flush eyes with large amounts of clear water for at least 15 minutes. If irritation persists, seek medical attention. SKIN: Immediately wash off with large amounts of water. If irritation persists, seek medical attention. In the event of overexposure due to inhalation, move victim to fresh air. If symptoms persist, seek medical attention. IF SWALLOWED: Do not induce vomiting. Drink large amounts of fruit juice or water. Do not give anything by mouth to an unconscious person. Seek medical attention.

SPECIFICATIONS:

APPEARANCE: Clear colorless to straw

FRAGRANCE: Cucumber

%AMMONIA: None

pH: 13+

DILUTION: As recommended above

VISCOSITY: < 5 cps

FLASH POINT F: Non-flammable

CLOUD POINT (Conc.): >125°F

%ACTIVE: 48 ± 2%

OVEN STABILITY (125F): Minimum 30 days

FREEZE/THAW STABILITY: Stable (minimum 3 cycles)

DENSITY: 8.62 lbs./gal.

Cello Professional Products

1354 Old Post Road
Havre de Grace, MD 21078
Toll Free: 800-638-4850
www.cello-online.com

Z52 0405