



**NEUTRA-STRIP®**  
**NEUTRAL pH STRIPPER**

**Z50**

# TECHNICAL DATA SHEET

## GENERAL INFORMATION

NEUTRA-STRIP is a revolutionary concept in floor finish removers. NEUTRA-STRIP is safe for both the user and the surroundings, while effectively removing build-ups of old floor finish from resilient flooring and hard surfaces. It's neutral pH formula contains no harsh ingredients such as ammonia, alcohol, butyl cellosolve, or caustic materials.

NEUTRA-STRIP is not flammable or combustible and is completely biodegradable.

### RECOMMENDED DILUTIONS

Dilute with cool water. NOTE: Do not use hot water.

Light/Medium Build-ups	25 oz./gal.	1:5
Heavy Build-ups	42 oz./gal.	1:3

## DIRECTIONS FOR AUTOMATIC SCRUBBERS:

1. Dilute NEUTRA STRIP according to directions, in the detergent solution tank. Release stripper generously over a manageable area with squeegee in up position.
2. Allow stripper to remain in contact with floor for at least 5 minutes. Scrub area until old finish is completely liquified. **IMPORTANT:** Do not allow stripper to dry on floor.
3. Pick up simultaneously during final scrub. Areas along baseboards and in corners may need to be done by hand using Cello ON & OFF and a doodle bug or stripping pad center.
4. Rinse area with cool, clean water using clean string mops, until there is no evidence of residue left on the floor. Allow to dry thoroughly.
5. Floor is now ready for recoating with any Cello quality floor finish.

## DIRECTIONS FOR MACHINE OR MOP STRIPPING

1. Spread properly diluted NEUTRA STRIP over a manageable area of the floor with a mop. Allow stripper to stand for at least 5 minutes. **IMPORTANT:** Do not allow stripper to dry on floor at any time.

**FOR MOP STRIPPING:** Agitate stripping solution with mop until old finish is completely liquified.

**FOR MACHINE STRIPPING:** Scrub floor with machine equipped with stripping pad or grip brush until old finish is completely liquified.

2. Pick up stripping solution with mop, wet pick-up vacuum, or auto scrubber.
3. Before any remaining stripper can dry, rinse floor thoroughly with cool, clean water and clean mop until all residue is removed. Allow floor to completely dry.
4. Floor is now ready for application of any Cello quality floor finish.

**CAUTION:** Eye irritant. Avoid contact with eyes.

**FIRST AID:** In the event of eye contact, flush eyes with large amounts of clear water for at least 15 minutes. If irritation persists, seek medical attention.

## SPECIFICATIONS

**APPEARANCE:** Clear green liquid

**FRAGRANCE:** Neutral

**pH:** 8.5 - 9.0

**DILUTION:** As recommended above

**% ACTIVE INGREDIENTS:** 33

**VISCOSITY:** Same as water

**FLASH POINT:** None

**FREEZE/THAW STABILITY:** Stable, minimum 3 cycles

**SHELF LIFE:** Minimum 1 year from manufacturer date of sale

**Cello Professional  
Products**

1354 Old Post Road  
Havre de Grace, MD 21078  
Toll Free: 800-638-4850  
www.cello-online.com

Z50 0205