



**SOLARINE®
METAL POLISH**

Z81

TECHNICAL DATA SHEET

Authorized by the USDA for use in federally inspected meat and poultry plants.

DIRECTIONS

FOR POLISHING COPPER UTENSILS:

1. Apply SOLARINE with a damp cloth or damp paper towel.
2. Clean copper by rubbing lightly.
3. Rinse thoroughly with water.
4. Wipe dry.

FOR POLISHING CHROME:

1. Apply SOLARINE with a damp cloth.
2. Do not rub, but allow liquid to dry to a powder for few minutes.
3. Wipe with a soft dry cloth.

FOR CLEANING AND POLISHING:

- Copper • Tile • Porcelain • Brass • Pewter • Nickel • Bronze • Tin • Marble
1. Apply SOLARINE with a soft cloth until stains and tarnish are removed.
 2. Then polish with a soft dry cloth.

FOR PORCELAIN, TILE, AND MARBLE:

1. Apply SOLARINE with a damp cloth or sponge. Because SOLARINE contains no silicate, the enamel on bathtubs, basins, and tile is not injured in any way. SOLARINE is superior to powder, as it will not scratch the finest surfaces nor leave any residue.
2. Rinse and buff dry.

CAUTION: Keep out of reach of children. Eye irritant. Avoid contact with eyes.

FIRST AID: In the event of eye contact, flush eyes with large amounts of clear water for at least 15 minutes, if irritation persists, seek medical attention.

SPECIFICATIONS

APPEARANCE: Tan paste

FRAGRANCE: Slight ammonia

TOTAL NON-VOLATILE MATERIAL: 30%

TOTAL ACTIVES: 31%

DENSITY: 9.9 lbs./gallon

SPECIFIC GRAVITY: 1.19

pH: 9.0 ± .2

FLASH POINT: None

SHELF LIFE: Indefinite

VISCOSITY: 5000 cps @ 20 RPM

Cello Professional Products

1354 Old Post Road
Havre de Grace, MD 21078
Toll Free: 800-638-4850
www.cello-online.com

Z81 0205